

Important Notice

To ensure that there are no non-release issues the clutch plate will need to be checked on the input shaft before installation. If it does not move up & down the input shaft freely, then file finish the clutch plate spline or contact NPC for a replacement.



Important Notice

To ensure that there are no non-release issues the clutch plate will need to be checked on the input shaft before installation. If it does not move up & down the input shaft freely, then file finish the clutch plate spline or contact NPC for a replacement.